

## APPRENDIMENTO DI UN TRASMETTITORE AVIDSEN 104250

Per apprendere un codice di un trasmettitore procedere come segue:

Accedere alla scheda radio aprendo la scatola della centralina, solitamente si trova in prossimità dell'automazione.

- 
1. Premere il pulsante contrassegnato con la sigla **RF** o **RX** (a seconda del modello) per 2 secondi, la luce del Led1 **rosso** si spegne poi rilasciare il pulsante.
  2. Premere il tasto del nuovo trasmettitore **entro 10 secondi**.  
Se il codice viene appreso il Led1 **rosso** sul ricevitore lampeggia per 3 volte a conferma della programmazione.

Attendere 10 secondi prima di provare il nuovo telecomando.

NOTE: La memoria può contenere fino a 10 telecomandi.

---

## English

For learn a code of a transmitter proceed as follows:

access the radio card by opening the box of the control unit usually located in the vicinity of the automation.

1. Press the the button marked with the initials RF or RX (depending on model) for 2 seconds, the light of the **red LED1** turns off then release the button.
2. Press the button on the transmitter again within 10 seconds.  
If the code is learned **Led1 on** the receiver flashes red 3 times to confirm the programming.

Wait 10 seconds before trying new remote control.

NOTE: The memory can store up to 10 remote controls.